TABLE OF CONTENTS

Index

For information regarding the equipment listed below, refer to the "Navigation System Owner's Manual".

- Navigation system
- Air conditioning
- Windshield wiper de-icer
- Rear view monitor system
- Intuitive parking assist

	٨	ŀ	/ · I			
•	Auc	lio/	'vıd	eo	SVS	tem

- Rear window and outside rear view mirror defoaaina
- Climate control
- · Wide view front monitor system

Before driving

1-1 Hybrid system Hybrid system......24 Hybrid system precautions 28 Energy monitor/consumption screen......33 Hybrid vehicle driving tips............ 38 1-2. Key information Kevs 40 1-3. Opening, closing and locking the doors Smart access system with push-button start 45 Doors...... 58 Trunk...... 61

1-4. Adjustable components (seats, mirrors, steering wheel)

Front seats	65
Driving position memory (driver's seat)	69
Head restraints	72
Seat belts	74
Steering wheel	80
Inside rear view mirror	82
Outside rear view mirrors	84

1-5. Opening and closing the windows and moon roof

Power windows	. 87
Moon roof	90

1-6. Refueling

Opening the fuel tank cap........... 94

1-7. Theft deterrent system

Alarm	100
Theft prevention labels	
(for U.S.A.)	103

Immobilizer system98

	Correct driving posture
2	When driving
2-1.	Driving procedures Driving the vehicle
2-2	Instrument cluster Gauges and meters

1-8. Safety information

2-3.	Operating the lights and
	windshield wipers

Headlight switch	186
Automatic High Beam	191
Fog light switch	197
Windshield wipers and	
washer	198
Headlight cleaner switch	203

2-4. Using other driving systems

Cruise control 204
Dynamic radar cruise
control 208
LKA (Lane-Keeping Assist) 221
Driving assist systems 229
Hill-start assist control 234
Pre-Collision System 236

2-5. Driving information

Cargo and luggage	245
Vehicle load limits	248
Winter driving tips	249
Trailer towing	252
Dinghy towing	253

3 Interior features	3-3. Using the Bluetooth audio
3-1. Using the air conditioning system and defogger Automatic air conditioning system	Bluetooth [®] audio system
Audio system	3-4. Using the hands-free phone system (for cellular phones) Hands-free system for cellular phones

3-6.	Using the storage features					
	List of storage features	367	4	Maintenance and care		
	Glove box Console box Cup holders	369	4-1.	Maintenance and care		
	Bottle holders Auxiliary boxes	373		Cleaning and protecting the vehicle exterior	408	
3-7.	Other interior features			Cleaning and protecting the vehicle interior	412	
	Sun visors		4-2.	Maintenance		
	Vanity mirrors			Maintenance requirements	415	
	Power outlets			General maintenance	417	
	Seat heaters and ventilators	379		Emission inspection and maintenance (I/M) programs	421	
	Rear sunshade	382	4-3.	Do-it-yourself maintenance		
	Floor mat Trunk compartment features Garage door opener Compass Safety Connect	386 388 396		Do-it-yourself service precautions	425 426 428 439 443 451 454	

	the vehicle interior	412
-2.	Maintenance	
	Maintenance requirements	415
	General maintenance	417
	Emission inspection and maintenance (I/M)	
	programs	421
-3.	Do-it-yourself maintenance	
	Do-it-yourself service	
	precautions4	
	Hood4	
	Positioning a floor jack4	-26
	Engine compartment4	-28
	12-volt battery 4	39
	Tires	43
	Tire inflation pressure	451
	Wheels 4	54
	Air conditioning filter4	56
	Electronic key battery4	-59
	Checking and replacing fuses	161
	Headlight aim	+01
	(LED headlights)	173
	Light bulbs4	
	g	_

5 When trouble arises

5-1.	Essential information		
	Emergency flashers	. 488	
	If your vehicle needs to be towed	. 489	
	If you think something is wrong	495	
	Event data recorder	496	
5-2.	-2. Steps to take in an emergency		
	If a warning light turns on or a warning buzzer		
	sounds	. 498	
	If a warning message is displayed	507	
	If you have a flat tire	527	
	If the hybrid system will not start	537	
	If you lose your keys	. 539	
	If the electronic key does not operate properly	. 540	
	If the vehicle 12-volt battery is discharged	543	
	If your vehicle overheats	. 548	
	If the vehicle becomes stuck	552	
	If your vehicle has to be stopped in		
	an emergency	. 554	

6 Vehicle specifications

6-1	-	Specifications
		Maintenance data
		(fuel, oil level, etc.) 556
		Fuel information 565
		Tire information 568
4.5)	Customization
0-2		
		Customizable features 580
6-3	3.	Initialization
		Items to initialize592
7	F	or owners
		Reporting safety defects

Abbreviation list	608
Alphabetical index	610
What to do if	624